

# 440-1995F3AE(MERCEDES BENZ E-CLASS W212 SDN '13-)

## 裝配說明書 Assembly Manual

1.先將原廠燈具拆下後，將帝寶燈具裝配於鈹金上。(見附圖 01)

1.Demount the original lamp and assemble the DEPO lamp on car sheet metal (See Fig. 01 )



附圖 01 (See Fig. 01)

2.將右邊燈具上紅/黑線接頭穿過行李箱鈹金內到達左邊。(見附圖 02-03)

2.Put the red-black wires connector of right lamp through the inner side of trunk medal sheet to the left side . (See Fig. 02-03)



附圖 02 (See Fig. 02)



附圖 03 (See Fig. 03)

3.將右邊接頭與左邊接頭搭在一起。(見附圖 04)

3.Put the right and left connectors together.(See Fig.04)



附圖 04 (See Fig. 04)

※你必須將右邊插頭和左邊插頭搭接一起(紅/黑線)，否則故障警示燈將會變成跑馬燈模式。

※Must put right and left connector together(red-black wires) , otherwise the warning light would run as dynamic mode.